

F24-60 Wiring Diagram (Standard)

Common line	Relay contact	Command	wire No.	Remark	
		AC-1	2-1		
		AC-2	2-2		
		MAIN-IN	2-3		
		MAIN-OUT	2-4		
			COM1	2-21	
			COM2	2-22	
			COM3	2-23	
			COM4	2-24	
		Ry1	F1	1-1	
		Ry2	R0/START	1-2	
		Ry3	R1	1-3	
		Ry4	R2	1-4	
		Ry5	R3	1-5	
		Ry6	R4	1-6	
		Ry7	SWA	1-7	
		Ry8	SWBA	1-8	
		Ry9	SWBB	1-9	
		Ry10	SWCA	1-10	
		Ry11	SWCB	1-11	
		Ry12	SWD	1-12	
		Ry13	1Y(U)1	1-13	
		Ry14	1Y(D)1	1-14	
		Ry15	1Y(U/D)2	1-15	
		Ry16	1Y(U/D)3	1-16	
		Ry17	1Y(U/D)4	1-17	
		Ry18	1Y(U/D)5	1-18	
		Ry19	1X(L)1	1-19	
		Ry20	1X(R)1	1-20	
		Ry21	1X(L/R)2	1-21	
		Ry22	1X(L/R)3	1-22	
		Ry23	1X(L/R)4	1-23	
		Ry24	1X(L/R)5	1-24	
		Ry25	2Y(U)1	2-5	
		Ry26	2Y(D)1	2-6	
		Ry27	2Y(U/D)2	2-7	
		Ry28	2Y(U/D)3	2-8	
		Ry29	2Y(U/D)4	2-9	
		Ry30	2Y(U/D)5	2-10	
		Ry31	2X(L)1	2-11	
		Ry32	2X(R)1	2-12	
	Ry33	2X(L/R)2	2-13		
	Ry34	2X(L/R)3	2-14		
	Ry35	2X(L/R)4	2-15		
	Ry36	2X(L/R)5	2-16		
	Ry37	(AUX)1	2-17		
	Ry38	(AUX)2	2-18		
	Ry39	(AUX)3	2-19		
	Ry40	(AUX)4	2-20		